

Item	Brand Name	Model
1	Acer	acer E400
2	Acer	acer P400
3	Acer	beTouch E210
4	Acer	DX650
5	Acer	E200
6	Acer	Liquid E
7	Acer	Liquid Mini (E310)
8	Acer	M900
9	Acer	S110
10	Acer	Smart handheld
11	Acer	Smart handheld
12	Acer	Smart handheld E100
13	Acer	Smart handheld E101
14	Adec & Partner AG	AG vegas
15	Alcatel	MISS SIXTY MSX10
16	Alcatel	OT-800/ OT-800A
17	Alcatel	OT-802/ OT-802A
18	Alcatel	OT-806/ OT-806A/ OT-806D/ OT-807/ OT-807A/ OT-807D
19	Alcatel	OT-808/ OT-808A
20	Alcatel	OT-880/ OT-880A
21	Alcatel	OT-980/ OT-980A
22	Altek	Altek A14
23	Amgoo Telecom Co LTD	AM83
24	Apple	iPhone 2G
25	Apple	iPhone 3G
26	Apple	iPhone 3Gs
27	Apple	iPhone 4
28	Apple	iPhone 4S
29	Apple	iPhone 5
30	Aramasmobile.com	ZX021
31	Ascom Sweden AB	3749
32	Asustek	1000846
33	Asustek	A10
34	Asustek	G60
35	Asustek	Galaxy3_L and Galaxy3_S
36	Asustek	Garmin-ASUS M10E
37	Asustek	P320
38	Asustek	P565c
39	Broadcom Corporation	BTL-A
40	Casio Hitachi	C721
41	Cellnet 7 Inc.	DG-805
42	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2052,
43	Cellon Communications Technology(Shenzhen) Co., Ltd.	C2053,
44	Cellon Communications Technology(Shenzhen) Co., Ltd.	C3031
45	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5030,
46	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5031,
47	Cellon Communications Technology(Shenzhen) Co., Ltd.	C5136,
48	Cellon Communications Technology(Shenzhen) Co., Ltd.	C7519
49	Cellon Communications Technology(Shenzhen) Co., Ltd.	C8093,
50	Cellon Communications Technology(Shenzhen) Co., Ltd.	Claro ADR1105,
51	Cellon Communications Technology(Shenzhen) Co., Ltd.	PCD ADR1105,
52	Chi Mei	AQ4
53	Chi Mei	P300
54	Chi Mei Communication Systems, Inc.	VIZIO (VPHN1044G)
55	China Bird (HK) Limited	Carisma 150
56	Cisco	Cius
57	Cisco	CP-7926G VoIP Telephone
58	Dell Computer Corporation	M01M
59	Dell Computer Corporation	V03B
60	Dell Computer Corporation	V03B, V03B001, V03B002
61	Doro AB	Doro PhoneEasy® 610
62	Doro AB	Doro PhoneEasy® 615
63	ecom instruments GmbH	Ex-Handy 07 .0 -A

Item	Brand Name	Model
64	ecom instruments GmbH	Ex-Handy 07 .0 -E
65	ecom instruments GmbH	Ex-Handy 07 .2 -A
66	ecom instruments GmbH	Ex-Handy 07 .2 -E
67	FIH	FM600
68	FIH	N700
69	FIH	PDA Phone
70	FIH	test_RM-383
71	FIH	ViewPad7
72	FIH CO., LTD	FAD
73	FIH CO., LTD	VS14034
74	Fujitsu	T-01C
75	Fujitsu Limited	F-12C
76	Fusion Garage Pte Ltd	Grid4
77	Garmin asus	G60
78	Global High Tech	GHT Maestro
79	Google	Google Nexus S
80	HAUS	JS100
81	Hewlett-Packard	HSTNH-P21C
82	HP	iPAD912
83	HTC	7 Pro
84	HTC	ADR6200VW
85	HTC	ADR6300
86	HTC	ADR6300
87	HTC	ADR6330VW
88	HTC	ADR6400L
89	HTC	ADR6425 LVW
90	HTC	ADR6425LVW
91	HTC	Amaze 4G
92	HTC	CDMA HTI11
93	HTC	CEDA100 Series
94	HTC	CEDA100 Series
95	HTC	CEDA100 Series (WM6.5)
96	HTC	ChaCha
97	HTC	Dash 3G
98	HTC	Desire
99	HTC	Droid DNA
100	HTC	Droid Eris
101	HTC	Droid Incredible 4G LTE
102	HTC	EVO
103	HTC	Evo 4G
104	HTC	FUZE (TM) P4600
105	HTC	G1
106	HTC	HD mini
107	HTC	HD2
108	HTC	HD7
109	HTC	Hero
110	HTC	Hero
111	HTC	HERO200
112	HTC	Incredible
113	HTC	Magic
114	HTC	MyTouch 3g
115	HTC	Nexus One
116	HTC	Nexus One
117	HTC	One
118	HTC	One X
119	HTC	One X+
120	HTC	Ozone
121	HTC	PB00 Series
122	HTC	PB65 series
123	HTC	PB76100
124	HTC	PB81 Series
125	HTC	PB92100
126	HTC	PB92110
127	HTC	PB92110 series
128	HTC	PB99 (CDMA)
129	HTC	PB99 Android 2.2 series
130	HTC	PB99400
131	HTC	PC10100
132	HTC	PC10xxx
133	HTC	PC36100
134	HTC	PC36100
135	HTC	PC36XXX
136	HTC	PC40100

Item	Brand Name	Model
137	HTC	PC402XX
138	HTC	PC402XX
139	HTC	PC57 Series
140	HTC	PC63xxx Android 2.2
141	HTC	PC70 series
142	HTC	PC92xxx
143	HTC	PC931XX
144	HTC	PC96 Series
145	HTC	PC991XX
146	HTC	PC992XX
147	HTC	PD051XX
148	HTC	PD06100
149	HTC	PD11 Series
150	HTC	PD112xx
151	HTC	PD15xxx
152	HTC	PD2610000
153	HTC	PD261XX
154	HTC	PD29xxx
155	HTC	PD421XX
156	HTC	PD42XXX
157	HTC	PD67100
158	HTC	PD98xxx(A9192)
159	HTC	PG05XXX
160	HTC	PG061XX
161	HTC	PG06XXX
162	HTC	PG321XX
163	HTC	PG321XX
164	HTC	PG32XXX
165	HTC	PG32XXX
166	HTC	PG41xxx
167	HTC	PG58100
168	HTC	PG59xxx
169	HTC	PG7624000
170	HTC	PG762XX
171	HTC	PG76XXX
172	HTC	PG86xxx
173	HTC	PG88xxx
174	HTC	PH11xxx
175	HTC	PH39xxx
176	HTC	PH44XXX
177	HTC	PH85xxx
178	HTC	PI06XXX
179	HTC	PI391XX
180	HTC	PI39XXX
181	HTC	PI42XXX
182	HTC	PI46xxx
183	HTC	PI86XXX
184	HTC	PJ03XXX
185	HTC	Pure
186	HTC	Rezound
187	HTC	RHOD100 Series
188	HTC	RHOD50000 Series
189	HTC	SHADOW
190	HTC	Shadow 2009
191	HTC	SMT 5800
192	HTC	Snap
193	HTC	Snap
194	HTC	Surround
195	HTC	Tattoo
196	HTC	Tilt 2
197	HTC	Titan 2
198	HTC	Touch 3G
199	HTC	Touch Diamond
200	HTC	Touch Diamond 2 T5353
201	HTC	Touch Diamond2
202	HTC	Touch Dual
203	HTC	Touch HD
204	HTC	Touch Pro
205	HTC	Touch Pro 2
206	HTC	Touch Pro2
207	HTC	Touch2
208	HTC	TWIN10000 Series
209	HTC	WHIT10000 Series

Item	Brand Name	Model
210	HTC	Wildfire
211	HTC	Wildfire A3333
212	HTC	Windows Phone 8X
213	HUAWEI	007HW
214	HUAWEI	C5120
215	HUAWEI	C8150
216	HUAWEI	C8150-1
217	HUAWEI	C8500
218	HUAWEI	C8600/ HUAWEI M860
219	HUAWEI	C8850
220	HUAWEI	D51-1
221	HUAWEI	G5500
222	HUAWEI	G5510
223	HUAWEI	G6008
224	HUAWEI	G6050
225	HUAWEI	G6151
226	HUAWEI	G6605
227	HUAWEI	G6608
228	HUAWEI	G6609
229	HUAWEI	G6620
230	HUAWEI	G6626
231	HUAWEI	G7050
232	HUAWEI	G7205
233	HUAWEI	G7210 / PANAMA CU
234	HUAWEI	G7300
235	HUAWEI	GM Ultimate Slim/ HUAWEI U8510-1/ U8510-1
236	HUAWEI	M615
237	HUAWEI	M635
238	HUAWEI	M835/ M835
239	HUAWEI	M865, M865, HUAWEI M865 MUVE
240	HUAWEI	M886/ M886/ HUAWEI C8860/ C8860
241	HUAWEI	MTC 752
242	HUAWEI	PCDM650KT/ HUAWEI M650/ M650/ HUAWEI C8350/ C8350
243	HUAWEI	S31HW/ U8150-92/ HUAWEI U8150-92
244	HUAWEI	S7-105
245	HUAWEI	S7-201c
246	HUAWEI	S7-201u
247	HUAWEI	S7-202c
248	HUAWEI	S7-202u
249	HUAWEI	T2251
250	HUAWEI	T2281
251	HUAWEI	T2311
252	HUAWEI	T2361
253	HUAWEI	T5900
254	HUAWEI	T6300
255	HUAWEI	T8300
256	HUAWEI	T8600
257	HUAWEI	U2800
258	HUAWEI	U2801-34
259	HUAWEI	U5110h-1
260	HUAWEI	U5200
261	HUAWEI	U5300
262	HUAWEI	U6150
263	HUAWEI	U8150-A
264	HUAWEI	U8150-D
265	HUAWEI	U8160/ U8160/ Vodafone 858 Smart/ Vodafone 858/ VF858
266	HUAWEI	U8160-U/ U8160-U/ Vodafone 858 Smart/ Vodafone 858/ VF858
267	HUAWEI	U8180-1/ U8180-1/ HUAWEI U8180/ U8180/ Stockholm/ T-Mobile Rapport/ Android Edition™ StarShine
268	HUAWEI	U8180-7/ U8180-7
269	HUAWEI	U8300/ U8300
270	HUAWEI	U8350/ U8350/ U8350-1/ Barcelona/ Boulder
271	HUAWEI	U8350-3/ U8350-3
272	HUAWEI	U8350-51/ U8350-51
273	HUAWEI	U8500/ U8500/ HUAWEI U8500-6/ U8500-6
274	HUAWEI	U8520/ HUAWEI U8520-1/ HUAWEI U8520/ U8520-1
275	HUAWEI	U8520-51/ U8520-51
276	HUAWEI	U8650-1/ U8650-1
277	HUAWEI	U8650NFC-1/ U8650NFC-1
278	HUAWEI	U8652/ U8652/ Huawei U8652/ U8652-51
279	HUAWEI	U8800 Pro/ U8800 Pro
280	HUAWEI	U8800-51/ U8800-51
281	HUAWEI	U8820/ U8820/ Titan

Item	Brand Name	Model
282	HUAWEI	U8850-1
283	HUAWEI	U8860/ U8860/ Honor
284	HUAWEI	UM840
285	INQ Mobile	T2-219U/ T2-218U
286	inventec	S42HW
287	inventec	T-101
288	iWOW	Libero
289	JRD Communication (ShenZhen) Inc	one touch 678G
290	KT Tech	EV-S100
291	KT Tech	KM-S120
292	KT Tech	KM-S200
293	KT Tech	KM-S220
294	KT Tech	KM-S220H
295	KT Tech	KM-S300
296	Kyocera	C4700
297	Kyocera	CLIP
298	Kyocera	Glide-M1400
299	Kyocera	ISW11K
300	Kyocera	K50
301	Kyocera	M2000
302	Kyocera	M6000
303	Kyocera	Mobile Phone 16 (E76)
304	Kyocera	S1310
305	Kyocera	S1350
306	Kyocera	S2300
307	Kyocera	S2410
308	Kyocera	SANYO SCP-3810
309	Kyocera	SCP-2700
310	Kyocera	SCP-8600
311	Kyocera	SCP-8600
312	Kyocera	Taho E4100
313	Kyocera	Torino
314	LG	3G Mobile Phone (GD910)
315	LG	3G Mobile Phone (GT950)
316	LG	3G Mobile Phone (LG- GT540/ GT540f/ GT540g)
317	LG	3G Mobile Phone (LG-A340)
318	LG	3G Mobile Phone (LG-A350 / LG-A355 / LG-A360)
319	LG	3G Mobile phone (LG-C550 / LG-C550f)
320	LG	3G Mobile Phone (LG-C800)
321	LG	3G Mobile Phone (LG-C800G)
322	LG	3G Mobile Phone (LG-E300)
323	LG	3G Mobile Phone (LG-E510 / LG-E510f / LG-E510g)
324	LG	3G Mobile Phone (LG-GB258)
325	LG	3G Mobile Phone (LG-P350)
326	LG	3G Mobile Phone (LG-P690 / LG-P692 / LG-P690f / LG-P690g)
327	LG	3G Mobile Phone (LG-P690b)
328	LG	3G Mobile Phone (LG-P698 / LG-P698f)
329	LG	3G Mobile Phone (LG-P699)
330	LG	3G Mobile Phone(GM730E)
331	LG	3G Mobile Phone(GW820)
332	LG	3G Mobile Phone(KB770, KB775, KB775f)
333	LG	3G Mobile Phone(LG-A353)
334	LG	3G Mobile Phone(LG-KU3800)
335	LG	3G Mobile Phone(LG-T320, LG-T320e, LG-T320g, LG-T320v, LG-T320k, LG-T320gv)
336	LG	A340
337	LG	BL20df/ BL20cf
338	LG	BL20v
339	LG	BL40
340	LG	BL40/ BL40g/ BL40f
341	LG	BL40e
342	LG	BL42/ BL42e/ BL42v/ BL42k/ BL42N/ BL20/ BL20e/ BL20v/ BL20k/
343	LG	CD02/ VER-01
344	LG	CDMA Mobile Phone (LG-CX7100)
345	LG	CDMA Mobile Phone (LG-LG5500X for Koodo)
346	LG	CDMA Mobile Phone (LG-LS700/ LG-VS700/ LG-US700/ LG-AS700/ LG-CS700/ LG-LG701/ LG-VM701)
347	LG	CDMA Mobile Phone (LG-MN180)
348	LG	CDMA Mobile Phone (LG-SV850)
349	LG	CDMA Mobile Phone (LG-SV850)
350	LG	CDMA Mobile Phone (LG-UN200/ LG501C/ AN200/ VM200 / CM200 / BM200/ LW200/ MN200 / CX200B / CX200 / JN200)
351	LG	CDMA Mobile Phone (LG-VN251/ LG-UN251/ LG-MN251/ LG251)

Item	Brand Name	Model
352	LG	CDMA Mobile Phone (LG-VS910)
353	LG	CDMA Mobile Phone (VX7100)
354	LG	CDMA Mobile Phone (VX8575/ AX8575)
355	LG	CDMA Mobile Phone(LG LN510)
356	LG	CDMA Mobile Phone(LG- LN510)
357	LG	CDMA Mobile Phone(LG220C)
358	LG	CDMA Mobile Phone(LG-CX9200)
359	LG	CDMA Mobile Phone(LG-CX9600)
360	LG	CDMA Mobile Phone(LGL85C)
361	LG	CDMA Mobile Phone(LG-LS855/ LG-US855/ LG-AS855/ LG-LG855/ LG-VM855)
362	LG	CDMA mobile phone(LG-UX700, LG-AX700, MT700, LW700, LG700, CX700, MV700, MX700, MD700, VM700)
363	LG	CDMA Mobile Phone(LG-VN271/ LG-AN271/ LG-UN271)
364	LG	CDMA Phone (LG-SU780)
365	LG	CF360
366	LG	Chocolate Touch
367	LG	CT520
368	LG	Dare VX9700
369	LG	enV3
370	LG	enV3 VX9200
371	LG	Escape™
372	LG	eXpo (GW820)
373	LG	GB250
374	LG	GC900
375	LG	GC900/ GC900F
376	LG	GC900e
377	LG	GC970/ GC970h
378	LG	GD 580 Lollipop
379	LG	GD310 Ice Cream 2
380	LG	GD510
381	LG	GD510 Pop
382	LG	GD510N
383	LG	GD550
384	LG	GD550e
385	LG	GD570
386	LG	GD570AW, GD570AV
387	LG	GD880/ GC970
388	LG	GD880f, GD880g
389	LG	GD900
390	LG	GD900/ GD900e
391	LG	Glance
392	LG	GM210
393	LG	GM360i
394	LG	GM600
395	LG	GM730/ GM730f/ GM735/ GM730e
396	LG	GM750
397	LG	GM750h
398	LG	GM750Q
399	LG	GR700
400	LG	GS290
401	LG	GS390
402	LG	GS500
403	LG	GS500f for PCL
404	LG	GS500f, GS500g, GS500k, GS500v
405	LG	GS500gX
406	LG	GS505
407	LG	GSM Mobile Phone (LG-A290)
408	LG	GSM Mobile Phone (LG-C320i)
409	LG	GSM Mobile Phone (LG-C330i)
410	LG	GSM Mobile Phone (LG-T565/ LG-T575/ LG-T650)
411	LG	GSM/ GPRS/ EDGE Mobile Phone (GM360)
412	LG	GT350
413	LG	GT350F
414	LG	GT350i
415	LG	GT360
416	LG	GT370
417	LG	GT400/ GT405
418	LG	GT500/ GT505
419	LG	GT540
420	LG	GT550
421	LG	GT620
422	LG	GT950Q

Item	Brand Name	Model
423	LG	GU230
424	LG	GU280, GU285, GU285f, GU285g
425	LG	GU280f
426	LG	GU282
427	LG	GU285
428	LG	GU290/ GU290f
429	LG	GU290v
430	LG	GU295/ GU292
431	LG	GU295f, GU295g
432	LG	GU297 , GU297a
433	LG	GW300, LG900G
434	LG	GW300FD, GW305
435	LG	GW380/ GW370B/ GW375/ GW382f/ GW380f/ GW380g
436	LG	GW520
437	LG	GW525gX
438	LG	GW550
439	LG	GW550h
440	LG	GW620
441	LG	GW820, GW825, GW825v
442	LG	GX200
443	LG	GX500
444	LG	GX500
445	LG	INCITE
446	LG	Intuition
447	LG	IS11LG
448	LG	KC910
449	LG	KC910, KC910Q, KC910Qa, KC910e, KC910i
450	LG	KF900 Prada 2
451	LG	KM553
452	LG	KM555
453	LG	KM555
454	LG	KM555e
455	LG	KM555R
456	LG	KM570
457	LG	KM900
458	LG	KM900, LG KM900e, LG KM900f, LG KM900g
459	LG	KP275
460	LG	KP500
461	LG	KP500N
462	LG	KP501/ KP502/ KP550
463	LG	KP505
464	LG	KS360
465	LG	KS365
466	LG	KT770, KT770f
467	LG	L-01D
468	LG	L-02D, PR-01D
469	LG	L-04C
470	LG	L-07C
471	LG	LG230(CX230), LG231(CX231), LG231C(CX231C)
472	LG	LG265X
473	LG	LG370
474	LG	LG-3G Mobile phone (LG-C555)
475	LG	LG430G
476	LG	LG670
477	LG	LG700V, CX700V
478	LG	LG-A200
479	LG	LG-A230/ LG-A235/ LG-A225
480	LG	LG-A250 / LG-A255
481	LG	LG-A258
482	LG	LG-A310/ LG-A310f/ LG-A310k/ LG-A315/ LG-A315v
483	LG	LG-AS680
484	LG	LG-AX265
485	LG	LG-AX265 [Not Approved by SIG]
486	LG	LG-AX8370
487	LG	LG-AX840
488	LG	LG-C320
489	LG	LG-C330
490	LG	LG-C375/ LG-C370/ LG-C365/ LG-C360
491	LG	LG-C395
492	LG	LG-C510/ C510
493	LG	LG-C570f
494	LG	LG-C570g
495	LG	LG-C660/ LG-C660h/ LG-C660R

Item	Brand Name	Model
496	LG	LG-C710h/ LG-C710
497	LG	LG-C729
498	LG	LG-C900
499	LG	LG-C900N, LG-C900k, LG-C900B
500	LG	LG-CX5500X
501	LG	LG-CX670/ LGCX670
502	LG	LG-E500
503	LG	LG-E720, LG-E720b, LG-E720k
504	LG	LG-E730
505	LG	LG-E730f
506	LG	LG-E739
507	LG	LG-E900, LG-E900h
508	LG	LG-E906
509	LG	LG-F100S/ LG-F100L
510	LG	LG-GB250
511	LG	LG-GD970
512	LG	LG-GM310/ LG-GM310f/ LG-GM310g
513	LG	LG-GW370
514	LG	LG-GW520/ LG-GW525/ GW525f/ GW525g
515	LG	LG-GW610
516	LG	LG-GW820, LG-GW825
517	LG	LG-JN240
518	LG	LG-JS750, LG-JS750g
519	LG	LG-KH3400
520	LG	LG-KH3400
521	LG	LG-KH3900
522	LG	LG-KH8000
523	LG	LG-KS720
524	LG	LG-KU2100, LG-SU210, LG-LU2100
525	LG	LG-KU2200
526	LG	LG-KU2800
527	LG	LG-KU5900
528	LG	LG-KU9300
529	LG	LG-KV700 (Lollipop2)
530	LG	LG-KV700T
531	LG	LG-KW730
532	LG	LGL45C
533	LG	LGL55C
534	LG	LG-L95G
535	LG	LG-LB4400
536	LG	LG-LG265T
537	LG	LG-LG8575/ LG-MX8575
538	LG	LG-LN272 / LG272 / LG272c
539	LG	LG-LS685
540	LG	LG-LS696
541	LG	LG-LS831/ LG-T130L/ LG-US831/ LG-AS831
542	LG	LG-LS840
543	LG	LG-LU2700
544	LG	LG-LU3000
545	LG	LG-LU4500
546	LG	LG-LU6500
547	LG	LG-LU6800
548	LG	LG-LU9400
549	LG	LG-LU9400W
550	LG	LG-LX295/ LG-LX290
551	LG	LG-MS695
552	LG	LG-MS840
553	LG	LG-MS910
554	LG	LG-MT375
555	LG	LG-P500/ LG-P509/ LG-P509TN
556	LG	LG-P500/ LG-P509TN/ LG-P509BK/ LG-P509MZ/ LG-P500h/ LG-P503/ LG-P505/ LG-P504/
557	LG	LG-P500h
558	LG	LG-P501
559	LG	LG-P503
560	LG	LG-P504
561	LG	LG-P505
562	LG	LG-P505R/ LG-P505CH
563	LG	LG-P506
564	LG	LG-P920/ LG-P925/ LG-P929
565	LG	LG-P925g, LG-P920h
566	LG	LG-P930
567	LG	LG-P935

Item	Brand Name	Model
568	LG	LG-P940, LG-SU540, LG-KU5400, LG-LU5400, L-02D
569	LG	LG-P970
570	LG	LG-P970G
571	LG	LG-P970h
572	LG	LG-P990
573	LG	LG-P990h
574	LG	LG-P999
575	LG	LG-P999DW
576	LG	LG-S365/ LG-S360
577	LG	LG-S367
578	LG	LG-SB210
579	LG	LG-SB260
580	LG	LG-SH560/ LG-KH5800
581	LG	LG-SH840, LG-KH8400
582	LG	LG-SU310, LG-LU3100
583	LG	LG-SU370/ LG-KU3700/ LG-LU3700
584	LG	LG-SU410
585	LG	LG-SU420/ LG-KU4200
586	LG	LG-SU430/ LG-KU4300/ LG-LU4300
587	LG	LG-SU540/ LG-KU5400/ LG-LU5400
588	LG	LG-SU640/ LG-LU6200
589	LG	LG-SU660
590	LG	LG-SU760
591	LG	LG-SU880
592	LG	LG-SU910/ LG-KU9100/ LG-LU9100
593	LG	LG-SU950/ KU9500
594	LG	LG-SU960, LG-KU9600
595	LG	LG-SV400
596	LG	LG-SV770
597	LG	LG-T325 , LG-T325f, LG-T325g
598	LG	LG-T500/ LG-T505/ LG-T507/ LG-T510/ LG-T515/ LG-T520/ LG-
599	LG	LG-T565b
600	LG	LG-UN150/ LG-VN150/ LG221C/ LG235C/ LG-MN150/ LW150/ LG-VP150/ LG150
601	LG	LG-UN270
602	LG	LG-UN430
603	LG	LG-UN431/ AN431/ LG431
604	LG	LG-US760
605	LG	LG-UX310, AX310, MT310(MetroPCS), LP310, LW310(LeapWireless(Cricket)), G310, CX310, MV310, MX310,
606	LG	LG-V150
607	LG	LGVN270/ LN270/ UN270/ LG270/ LG270C/ LW270/ CX270/ MN270/ TN270/ AN270/ VM270
608	LG	LG-VN530
609	LG	LG-VS660/ LS670/ US670/ LG670C/ MS690/ LW690/ VM670/
610	LG	LG-VS740/ US740/ MS740/ AS740
611	LG	LG-VS750
612	LG	LG-VS760
613	LG	LG-VS761
614	LG	LG-VS840
615	LG	LG-VS920
616	LG	LG-VX11000
617	LG	LG-VX8576
618	LG	LG-VX9200
619	LG	LN240/ MN240/ LW240/ UN240/ AN240/ VN240/ CX240
620	LG	Lotus LX600
621	LG	LU2300
622	LG	LW375
623	LG	LX290
624	LG	LX370
625	LG	LX610/ UX610/ CX610/ LG610/ VM610/ AX610/ UN610/ CN610/ VN610/ AN610
626	LG	MT375
627	LG	Neon (TM) GT365
628	LG	New LG 3G Mobile Phone(GD710)
629	LG	New LG CDMA Mobile Phone(LG-LG290C)
630	LG	Optimus G
631	LG	Rumor 2
632	LG	Scoop / AX-260
633	LG	Shine 2
634	LG	Shine II GD710 AT&T
635	LG	Shine KE970
636	LG	TD-SCDMA Mobile Phone (GT910s)

Item	Brand Name	Model
637	LG	TD-SCDMA Mobile Phone(LG KT878)
638	LG	UX220
639	LG	UX370
640	LG	VER-01
641	LG	Versa
642	LG	VN250
643	LG	Vortex
644	LG	Voyager VX10000
645	LG	VX5500
646	LG	VX5600
647	LG	VX8360
648	LG	VX8370
649	LG	VX8610
650	LG	VX9600
651	LG	WCDMA Mobile Phone (LG-SU550)
652	LG	WCDMA Mobile Phone (LG-SU920, LG-KU9200)
653	LG	WCDMA Mobile Phone(LG-SU130)
654	LG	WCDMA Mobile Phone(LG-SU630)
655	LG	WCDMA Mobile Phone(LG-SU900/ LG-KU9000/ LG-LU9000)
656	LG	X350
657	LG	Xenon (TM) GR500
658	LG	Xpression™
659	LG	LX400
660	MediaTek	Mediatek Bluetooth® Host SW 4.0 + HS
661	MediaTek	MediaTek BlueZ (2.1+EDR)
662	MediaTek	Mediatek WM6.5 (EDR2.0)
663	MediaTek	Phone
664	Microsoft	Windows Phone 7
665	Motorola	Backflip ME600
666	Motorola	EM35
667	Motorola	Z9N
668	Motorola	A3300c
669	Motorola	A853
670	Motorola	A855
671	Motorola	A955
672	Motorola	Amphora-i897
673	Motorola	Athens-i9 R2
674	Motorola	Atrix 2
675	Motorola	Atrix HD
676	Motorola	Backflip MB300
677	Motorola	Banfi-i856
678	Motorola	Bei Hai TD
679	Motorola	Blackstone-R2
680	Motorola	Brightwater
681	Motorola	Castle
682	Motorola	Cliq
683	Motorola	Cliq MB200
684	Motorola	Clutch (i465)
685	Motorola	Cordova
686	Motorola	Creekside-i886
687	Motorola	CRUSH
688	Motorola	Devour
689	Motorola	Dext
690	Motorola	Droid
691	Motorola	Droid 2
692	Motorola	Droid 4
693	Motorola	Droid Pro
694	Motorola	Droid Razr
695	Motorola	Droid Razr HD
696	Motorola	Droid Razr Maxx HD
697	Motorola	Droid X
698	Motorola	E1
699	Motorola	E1070
700	Motorola	E398
701	Motorola	E8
702	Motorola	EM30
703	Motorola	EWP3100
704	Motorola	Fairbanks
705	Motorola	Finch
706	Motorola	FR6070, FR6076
707	Motorola	FR6874
708	Motorola	Halo
709	Motorola	Heartland

Item	Brand Name	Model
710	Motorola	i296-Gallo
711	Motorola	i365
712	Motorola	i410(Nevadacity)
713	Motorola	i576
714	Motorola	i686-Brightwater-2
715	Motorola	i776
716	Motorola	i786w (Mantra)
717	Motorola	I9
718	Motorola	K3
719	Motorola	Karma QA1
720	Motorola	MB200 refresh
721	Motorola	MB300 Backflip refresh
722	Motorola	MB501 refresh
723	Motorola	MB502
724	Motorola	MB508
725	Motorola	MB511
726	Motorola	MB520
727	Motorola	MB525
728	Motorola	MB810
729	Motorola	ME811
730	Motorola	Milestone XT720
731	Motorola	MOTO (TM) Z9
732	Motorola	Moto A3000
733	Motorola	Motosurf A3000
734	Motorola	Motosurf A3100
735	Motorola	MT716
736	Motorola	Muscardini
737	Motorola	Oaknoll
738	Motorola	Q11
739	Motorola	Q9H
740	Motorola	Quailhurst iDEN-i786
741	Motorola	RAZR V3
742	Motorola	RAZR V3xx Pink
743	Motorola	RAZR2 V9
744	Motorola	Rival
745	Motorola	RIVAL (TELUS)
746	Motorola	Rush
747	Motorola	SLVR L72
748	Motorola	U9
749	Motorola	V1100
750	Motorola	V360
751	Motorola	V365
752	Motorola	V3i
753	Motorola	V3x
754	Motorola	V500
755	Motorola	V550
756	Motorola	V551
757	Motorola	V6
758	Motorola	V750
759	Motorola	V80
760	Motorola	V860
761	Motorola	V9
762	Motorola	V950
763	Motorola	V9x
764	Motorola	VE20
765	Motorola	VE440
766	Motorola	VE66
767	Motorola	VoWLAN Single Mode Smartphone
768	Motorola	VU30
769	Motorola	W418G
770	Motorola	W510
771	Motorola	W755
772	Motorola	W766
773	Motorola	W766
774	Motorola	WX345
775	Motorola	WX404
776	Motorola	XT502
777	Motorola	XT610
778	Motorola	XT701
779	Motorola	XT701 Milestone
780	Motorola	XT702
781	Motorola	XT711
782	Motorola	XT720

Item	Brand Name	Model
783	Motorola	XT800
784	Motorola	XT800+
785	Motorola	XT800c
786	Motorola	XT800W
787	Motorola	XT806
788	Motorola	Z3
789	Motorola	Z6w
790	Motorola	ZN300
791	Motorola	ZN4
792	Motorola	ZN5
793	Motorola	A953
794	Motorola	A955
795	Motorola	A956
796	Motorola	A956
797	Motorola	A957
798	Motorola	Birdstone i475,
799	Motorola	Brea
800	Motorola	BRIDGEVIEW iDEN
801	Motorola	DominoV
802	Motorola	EX108
803	Motorola	EX109
804	Motorola	EX118
805	Motorola	EX130
806	Motorola	EX132
807	Motorola	EX139
808	Motorola	EX212
809	Motorola	EX223
810	Motorola	EX232
811	Motorola	Fawnridge i940
812	Motorola	GSM mobile phone
813	Motorola	Hallcrest (WX 430)
814	Motorola	i475 (Birdstone)
815	Motorola	Jorian-xt605
816	Motorola	MB508
817	Motorola	MB520
818	Motorola	MB525
819	Motorola	MB611
820	Motorola	MB612
821	Motorola	MB810
822	Motorola	MB810 UR
823	Motorola	MB861
824	Motorola	MB870
825	Motorola	ME860
826	Motorola	MOSAIC-i440
827	Motorola	MT620
828	Motorola	MT810LX
829	Motorola	MT870
830	Motorola	Style
831	Motorola	Titanium
832	Motorola	W409G
833	Motorola	WX292
834	Motorola	WX294
835	Motorola	WX346
836	Motorola	WX445
837	Motorola	XT300
838	Motorola	XT301
839	Motorola	XT311
840	Motorola	XT311
841	Motorola	XT317
842	Motorola	XT530
843	Motorola	XT531
844	Motorola	XT532
845	Motorola	XT610
846	Motorola	XT610
847	Motorola	XT615
848	Motorola	XT860
849	Motorola	XT862
850	Motorola	XT865
851	Motorola	XT875
852	Motorola	XT882
853	NEC CASIO	C781
854	NEC CASIO	CA-01C
855	NEC CASIO	G'zOne

Item	Brand Name	Model
856	NEC CASIO	G'zOne
857	NEC CASIO	IS11CA
858	NEC CASIO	KMP7N4AB-1A
859	NEC CASIO	N-02D
860	NEC CASIO	N-04C
861	NEC CASIO	N-05C
862	NEC CASIO	N-06C
863	NEC CASIO	KMP7N4Y1-2A
864	Nokia	200
865	Nokia	201
866	Nokia	300
867	Nokia	303
868	Nokia	500
869	Nokia	600
870	Nokia	603
871	Nokia	700
872	Nokia	701
873	Nokia	1006
874	Nokia	2000
875	Nokia	2010
876	Nokia	2605
877	Nokia	2705
878	Nokia	2705
879	Nokia	2705
880	Nokia	2730
881	Nokia	2760
882	Nokia	3000
883	Nokia	3030
884	Nokia	3555
885	Nokia	3711
886	Nokia	5132
887	Nokia	5220
888	Nokia	5230
889	Nokia	5310
890	Nokia	5320
891	Nokia	5530
892	Nokia	5610
893	Nokia	5611
894	Nokia	5800
895	Nokia	6085
896	Nokia	6086
897	Nokia	6103
898	Nokia	6133
899	Nokia	6205
900	Nokia	6263
901	Nokia	6301
902	Nokia	6350
903	Nokia	6555
904	Nokia	6600
905	Nokia	6650
906	Nokia	6700
907	Nokia	6730
908	Nokia	6788
909	Nokia	7205
910	Nokia	7205
911	Nokia	7208
912	Nokia	7208
913	Nokia	7310
914	Nokia	7510
915	Nokia	7705
916	Nokia	7705
917	Nokia	7705
918	Nokia	8208
919	Nokia	8800
920	Nokia	2332c
921	Nokia	2600C
922	Nokia	2680s
923	Nokia	2720 Fold
924	Nokia	2730 Classic
925	Nokia	3208c
926	Nokia	3710 fold
927	Nokia	3720c-2
928	Nokia	5130 XpressMusic

Item	Brand Name	Model
929	Nokia	5230 Nuron
930	Nokia	5330TV
931	Nokia	5630Xpress
932	Nokia	5730s-1
933	Nokia	6220c
934	Nokia	6303C
935	Nokia	6303c
936	Nokia	6316s, 6316s-1
937	Nokia	6350-1b
938	Nokia	6350-1d
939	Nokia	6500 Slide
940	Nokia	6600i Slide
941	Nokia	6600i-1c
942	Nokia	6700 Clasic
943	Nokia	6700 slide
944	Nokia	6700c
945	Nokia	6700c-1
946	Nokia	6750-1b
947	Nokia	6750-1c
948	Nokia	6760s-1
949	Nokia	6788i
950	Nokia	6790s-1b
951	Nokia	6790s-1c
952	Nokia	702T
953	Nokia	7100 Supernova
954	Nokia	7210 Supernova
955	Nokia	7505 CDMA Mobile Phone
956	Nokia	7610s
957	Nokia	801T
958	Nokia	C1-03
959	Nokia	C2-00
960	Nokia	C2-02
961	Nokia	C2-02.1
962	Nokia	C2-03
963	Nokia	C2-05
964	Nokia	C2-05.1
965	Nokia	C2-06
966	Nokia	C2-07
967	Nokia	C2-08
968	Nokia	C3-00.2
969	Nokia	C3-01.5
970	Nokia	C5-00
971	Nokia	C5-00.03
972	Nokia	C5-00.2
973	Nokia	C5-01
974	Nokia	C5-04.1
975	Nokia	C5-05
976	Nokia	C5-06
977	Nokia	C7-00.1
978	Nokia	C7-00s
979	Nokia	E52
980	Nokia	E6-00
981	Nokia	E63
982	Nokia	E66
983	Nokia	E71
984	Nokia	E71x
985	Nokia	E71x
986	Nokia	E72
987	Nokia	E75
988	Nokia	E75-1
989	Nokia	E75-2
990	Nokia	E90
991	Nokia	Lumia 800
992	Nokia	Lumia 820
993	Nokia	Lumia 900
994	Nokia	Lumia 920
995	Nokia	Mural (6750)
996	Nokia	N73
997	Nokia	N78
998	Nokia	N79
999	Nokia	N8
1000	Nokia	N85
1001	Nokia	N86

Item	Brand Name	Model
1002	Nokia	N9
1003	Nokia	N900
1004	Nokia	N96
1005	Nokia	N97
1006	Nokia	N97 Mini
1007	Nokia	Surge (TM) 6790
1008	Nokia	T7-00
1009	Nokia	Vertu ASCENT X
1010	Nokia	Vertu Constellation F
1011	Nokia	Vertu CONSTELLATION T
1012	Nokia	Vertu Signature SC
1013	Nokia	X2-02
1014	Nokia	X2-03
1015	Nokia	X2-05
1016	Nokia	X3
1017	Nokia	X3-01
1018	Nokia	X3-02.5
1019	Nokia	X3-02i
1020	Nokia	X5-00
1021	Nokia	X6
1022	Nokia	X6
1023	Nokia	X7
1024	Nokia	Z730C
1025	Palm	Centro
1026	Palm	P100EWW
1027	Palm	P100UNA/ P100UEU
1028	Palm	P101EWW
1029	Palm	P101UNA, P101UEU
1030	Palm	P120EWW
1031	Palm	P121EWW
1032	Palm	P121UNA, P121UEU
1033	Palm	Pixi
1034	Palm	Pixi Plus CDMA
1035	Palm	Pre
1036	Palm	Pre Plus CDMA
1037	Palm	Treo 680
1038	Palm	Treo 800w
1039	Palm	Treo Pro
1040	Palm	Treo Pro, T850EWW
1041	Panasonic	003P
1042	Panasonic	101P
1043	Panasonic	EB-3236
1044	Panasonic	EB-4054
1045	Panasonic	EB-4057
1046	Panasonic	KX-TU311
1047	Panasonic	P-01D
1048	Panasonic	P-02D
1049	Panasonic	P-07C
1050	Pantech	ADR8995
1051	Pantech	CDM8992
1052	Pantech	CDM8992
1053	Pantech	CDM8999**
1054	Pantech	CDMA PT106 (IS06)
1055	Pantech	CDMA EIS01PT(EIS01PT)
1056	Pantech	CDMA PT111(PTI11)
1057	Pantech	IM-A600S
1058	Pantech	IM-A630K (SP33K)
1059	Pantech	IM-A630K (SP33K)
1060	Pantech	IM-A650S
1061	Pantech	IM-A690L
1062	Pantech	IM-A690L
1063	Pantech	IM-A690S
1064	Pantech	IM-A690S
1065	Pantech	IM-A710K
1066	Pantech	IM-A710K
1067	Pantech	IM-A720L
1068	Pantech	IM-A720L
1069	Pantech	IM-A725L
1070	Pantech	IM-A730S
1071	Pantech	IM-A730S
1072	Pantech	IM-A740S
1073	Pantech	IM-A750K
1074	Pantech	IM-A760S

Item	Brand Name	Model
1075	Pantech	IM-A770K
1076	Pantech	IM-A775C
1077	Pantech	IM-A780L
1078	Pantech	IM-A800S
1079	Pantech	IM-A810K
1080	Pantech	IM-A810S
1081	Pantech	IM-T100K
1082	Pantech	Matrix Pro (TM)
1083	Pantech	MD Cube
1084	Pantech	P2000
1085	Pantech	P2020
1086	Pantech	P2030
1087	Pantech	P5000
1088	Pantech	P6010
1089	Pantech	P6020
1090	Pantech	P7000
1091	Pantech	P7040
1092	Pantech	P8000
1093	Pantech	P8000
1094	Pantech	P9020
1095	Pantech	P9050
1096	Pantech	Pantech Breeze III™
1097	Pantech	Pantech Burst™
1098	Pantech	Pantech Discover™
1099	Pantech	Pantech Flex
1100	Pantech	Pantech P9070
1101	Pantech	Pantech Pocket™
1102	Pantech	Pantech Reneue™
1103	Pantech	Pantech Swift™
1104	Pantech	PantechP7050
1105	Pantech	PantechP9060
1106	Pantech	PIVOT **
1107	Pantech	PIVOT/ TXT8030##
1108	Pantech	Show(TXT8040, VZW-1026)
1109	Pantech	TXT8035PP
1110	Pantech	TXT8040##
1111	Pantech	TXT8045US
1112	Pantech	TXT8045VW
1113	Pantech	WP8990
1114	PCD	Razzle TXT8060
1115	Pharos	PTL117
1116	Pharos	PTL127
1117	RIM	BlackBerry 8120
1118	RIM	Blackberry 8220
1119	RIM	Blackberry 8350i
1120	RIM	Blackberry 8530
1121	Rim	Blackberry 8820
1122	RIM	Blackberry 9300
1123	RIM	Blackberry 9500
1124	RIM	Blackberry 9530
1125	RIM	Blackberry 9630
1126	RIM	Blackberry 9700
1127	Rim	Blackberry Bold 9000
1128	RIM	BlackBerry Curve (8520)
1129	RIM	Blackberry Curve 3G 9300
1130	RIM	Blackberry Curve 3G 9330
1131	Rim	Blackberry Curve 8310
1132	Rim	Blackberry Curve 8320
1133	Rim	Blackberry Curve 8900
1134	Rim	Blackberry Pearl 8100
1135	Rim	Blackberry Pearl 8110
1136	RIM	Blackberry Storm 2
1137	RIM	BlackBerry Storm 9550 (Storm 2)
1138	RIM	BlackBerry Style (9670)
1139	RIM	BlackBerry Torch (9800)
1140	RIM	BlackBerry Z10
1141	RIM	BlackBerry® Bold™ 9790
1142	RIM	BlackBerry® Bold™ 9900
1143	RIM	BlackBerry® Bold™ 9900 Smartphone
1144	RIM	BlackBerry® Bold™ 9930 Smartphone
1145	RIM	BlackBerry® Curve™ 8980
1146	RIM	BlackBerry® Curve™ 9350 Smartphone

Item	Brand Name	Model
1147	RIM	BlackBerry® Curve™ 9360
1148	RIM	BlackBerry® Curve™ 9360 Smartphone
1149	RIM	BlackBerry® Curve™ 9370
1150	RIM	BlackBerry® Curve™ 9380
1151	RIM	BlackBerry® Torch™ 9810
1152	RIM	BlackBerry® Torch™ 9810 Smartphone
1153	RIM	BlackBerry® Torch™ 9850 Smartphone
1154	RIM	BlackBerry® Torch™ 9860 Smartphone
1155	RIM	BlackBerryR 8530 Smartphone
1156	RIM	BlackBerryR 8910 Curve Smartphone
1157	RIM	BlackBerryR Bold 9000
1158	RIM	BlackBerryR Bold 9650 Smartphone
1159	RIM	BlackBerryR Bold 9650 Smartphone
1160	RIM	BlackBerryR Bold 9700
1161	RIM	BlackBerryR Bold 9780 smartphone
1162	RIM	BlackBerryR Curve 8330
1163	RIM	BlackBerryR Curve 8350i
1164	RIM	BlackBerryR Curve 8520 Smartphone
1165	RIM	BlackBerryR Curve 8900
1166	RIM	BlackBerryR Curve 9300
1167	RIM	BlackBerryR Curve 9330 Smartphone
1168	RIM	BlackBerryR Pearl 8230
1169	RIM	BlackBerryR Pearl 9100 Smartphone
1170	RIM	BlackBerryR Pearl 9105 Smartphone
1171	RIM	BlackBerryR Storm 9500
1172	RIM	BlackBerryR Storm 9530
1173	RIM	BlackBerryR Storm2 9520
1174	RIM	BlackBerryR Storm2 9550
1175	RIM	BlackBerryR Style 9670 Smartphone
1176	RIM	BlackBerryR Torch 9800
1177	RIM	BlackBerryR Tour 9630 Smartphone
1178	RIM	RDL61TC
1179	Samsung	A237
1180	Samsung	a727
1181	Samsung	A737
1182	Samsung	a747
1183	Samsung	A767 Propel
1184	Samsung	A777
1185	Samsung	A827
1186	Samsung	Alias 2 U750
1187	Samsung	B2100
1188	Samsung	B7300
1189	Samsung	Behold 2 (T939)
1190	Samsung	Behold T919
1191	Samsung	BlackJack (TM) II (i617)
1192	Samsung	C3050
1193	Samsung	C3050
1194	Samsung	C3050
1195	Samsung	C3110
1196	Samsung	C3110H
1197	Samsung	C5130
1198	Samsung	C5212
1199	Samsung	C5510
1200	Samsung	C6625
1201	Samsung	Captivate (I897)
1202	Samsung	Captivate™ Glide
1203	Samsung	CDMA SC111
1204	Samsung	Continuum (I400)
1205	Samsung	D780
1206	Samsung	D880
1207	Samsung	D900i
1208	Samsung	D988
1209	Samsung	E3010
1210	Samsung	E390
1211	Samsung	Epic 4G (D700)
1212	Samsung	Eternity A867
1213	Samsung	Exhilarate
1214	Samsung	F110
1215	Samsung	F330
1216	Samsung	F480
1217	Samsung	F490
1218	Samsung	Fascinate (I500)
1219	Samsung	Flight

Item	Brand Name	Model
1220	Samsung	Focus@ 2
1221	Samsung	Focus™ S
1222	Samsung	Galaxy Exhilarate™
1223	Samsung	Galaxy Express™
1224	Samsung	Galaxy Nexus
1225	Samsung	Galaxy Note
1226	Samsung	Galaxy Note 2
1227	Samsung	Galaxy Rugby Pro™
1228	Samsung	Galaxy S2 Skyrocket
1229	Samsung	Galaxy S3
1230	Samsung	Galaxy S4
1231	Samsung	Galaxy Spica GT-i5700
1232	Samsung	Gravity 2 (T469)
1233	Samsung	Gravity T459
1234	Samsung	GT- S8500
1235	Samsung	GT-B2710
1236	Samsung	GT-B2710D
1237	Samsung	GT-B3210
1238	Samsung	GT-B3310
1239	Samsung	GT-B3310i
1240	Samsung	GT-B3313i
1241	Samsung	GT-B3410
1242	Samsung	GT-B3410R
1243	Samsung	GT-B3410W
1244	Samsung	GT-B5210U
1245	Samsung	GT-B5310
1246	Samsung	GT-B5310B
1247	Samsung	GT-B5310L
1248	Samsung	GT-B5310R
1249	Samsung	GT-B5310U
1250	Samsung	GT-B5510
1251	Samsung	GT-B5510B
1252	Samsung	GT-B5510L
1253	Samsung	GT-B5512
1254	Samsung	GT-B5512B
1255	Samsung	GT-B6520
1256	Samsung	GT-B6520L
1257	Samsung	GT-B7300
1258	Samsung	GT-B7300B
1259	Samsung	GT-B7300C
1260	Samsung	GT-B7320
1261	Samsung	GT-B7320L
1262	Samsung	GT-B7330
1263	Samsung	GT-B7330B
1264	Samsung	GT-B7330D
1265	Samsung	GT-B7330R
1266	Samsung	GT-B7350
1267	Samsung	GT-B7350T
1268	Samsung	GT-B7510
1269	Samsung	GT-B7510B
1270	Samsung	GT-B7510L
1271	Samsung	GT-B7610
1272	Samsung	GT-B7620
1273	Samsung	GT-B7620U
1274	Samsung	GT-C3010
1275	Samsung	GT-C3011
1276	Samsung	GT-C3013
1277	Samsung	GT-C3050
1278	Samsung	GT-C3050C
1279	Samsung	GT-C3053
1280	Samsung	GT-C3060
1281	Samsung	GT-C3200
1282	Samsung	GT-C3222W
1283	Samsung	GT-C3300
1284	Samsung	GT-C3300D
1285	Samsung	GT-C3300i
1286	Samsung	GT-C3300K
1287	Samsung	GT-C3303K
1288	Samsung	GT-C3310
1289	Samsung	GT-C3312
1290	Samsung	GT-C3322
1291	Samsung	GT-C3330
1292	Samsung	GT-C3332

Item	Brand Name	Model
1293	Samsung	GT-C3350
1294	Samsung	GT-C3500
1295	Samsung	GT-C3503
1296	Samsung	GT-C3510
1297	Samsung	GT-C3510T
1298	Samsung	GT-C3518
1299	Samsung	GT-C3520
1300	Samsung	GT-C3530
1301	Samsung	GT-C3560
1302	Samsung	GT-C3750
1303	Samsung	GT-C3752
1304	Samsung	GT-C5180
1305	Samsung	GT-C5510
1306	Samsung	GT-C5510H
1307	Samsung	GT-C5510U
1308	Samsung	GT-C6712
1309	Samsung	GT-E1232B
1310	Samsung	GT-E2152i
1311	Samsung	GT-E2220
1312	Samsung	GT-E2222
1313	Samsung	GT-E2222L
1314	Samsung	GT-E2230
1315	Samsung	GT-E2230L
1316	Samsung	GT-E2232
1317	Samsung	GT-E2330B
1318	Samsung	GT-E2530
1319	Samsung	GT-E2600
1320	Samsung	GT-E2652
1321	Samsung	GT-E2652W
1322	Samsung	GT-E3210
1323	Samsung	GT-E3210B
1324	Samsung	GT-E3210L
1325	Samsung	GT-E3210O
1326	Samsung	GT-E3213K
1327	Samsung	GT-E3217B
1328	Samsung	GT-I5500
1329	Samsung	GT-I5500B
1330	Samsung	GT-I5500L
1331	Samsung	GT-I5500M
1332	Samsung	GT-I5503T
1333	Samsung	GT-I5508
1334	Samsung	GT-I5510
1335	Samsung	GT-I5510 (GB)
1336	Samsung	GT-I5510B
1337	Samsung	GT-I5510L
1338	Samsung	GT-I5510M
1339	Samsung	GT-I5510T
1340	Samsung	GT-I5700
1341	Samsung	GT-I5700
1342	Samsung	GT-I5700L
1343	Samsung	GT-I5700U
1344	Samsung	GT-I5800
1345	Samsung	GT-I5800L
1346	Samsung	GT-I5801
1347	Samsung	GT-I6220
1348	Samsung	GT-I6230
1349	Samsung	GT-I6410
1350	Samsung	GT-I6500U
1351	Samsung	GT-I6500U
1352	Samsung	GT-I6712
1353	Samsung	GT-I7410
1354	Samsung	GT-I7500U
1355	Samsung	GT-I7680
1356	Samsung	GT-I8000
1357	Samsung	GT-I8000H
1358	Samsung	GT-I8000L
1359	Samsung	GT-I8000T
1360	Samsung	GT-I8150
1361	Samsung	GT-I8150B
1362	Samsung	GT-I8150T
1363	Samsung	GT-I8180C
1364	Samsung	GT-I8320
1365	Samsung	GT-I8330

Item	Brand Name	Model
1366	Samsung	GT-I8350
1367	Samsung	GT-I8350T
1368	Samsung	GT-I8520
1369	Samsung	GT-I8910L
1370	Samsung	GT-I8910U
1371	Samsung	GT-I9000
1372	Samsung	GT-I9000
1373	Samsung	GT-I9000B
1374	Samsung	GT-I9000L
1375	Samsung	GT-I9000M
1376	Samsung	GT-I9000M
1377	Samsung	GT-I9000T
1378	Samsung	GT-I9001
1379	Samsung	GT-I9003
1380	Samsung	GT-I9003
1381	Samsung	GT-I9003
1382	Samsung	GT-I9003L
1383	Samsung	GT-I9003L
1384	Samsung	GT-I9008
1385	Samsung	GT-I9008L
1386	Samsung	GT-I9008L
1387	Samsung	GT-I9010
1388	Samsung	GT-I9018
1389	Samsung	GT-I9020
1390	Samsung	GT-I9020
1391	Samsung	GT-I9020A
1392	Samsung	GT-I9020A
1393	Samsung	GT-I9020T
1394	Samsung	GT-I9020T
1395	Samsung	GT-I9023
1396	Samsung	GT-I9023
1397	Samsung	GT-I9070
1398	Samsung	GT-I9088
1399	Samsung	GT-I9100
1400	Samsung	GT-I9100
1401	Samsung	GT-I9100G
1402	Samsung	GT-I9100M
1403	Samsung	GT-I9100M
1404	Samsung	GT-I9100P
1405	Samsung	GT-I9100T
1406	Samsung	GT-I9100T
1407	Samsung	GT-I9103
1408	Samsung	GT-I9108
1409	Samsung	GT-I9188
1410	Samsung	GT-I9210
1411	Samsung	GT-I9220
1412	Samsung	GT-I9228
1413	Samsung	GT-I9250
1414	Samsung	GT-I9250M
1415	Samsung	GT-I9250T
1416	Samsung	GT-I9250W
1417	Samsung	GT-M2510
1418	Samsung	GT-M2510C
1419	Samsung	GT-M2513
1420	Samsung	GT-M2520
1421	Samsung	GT-M3710
1422	Samsung	GT-M7500C
1423	Samsung	GT-M7600B
1424	Samsung	GT-M7600H
1425	Samsung	GT-M7600L
1426	Samsung	GT-M7603
1427	Samsung	GT-M8910
1428	Samsung	GT-M8910B
1429	Samsung	GT-M8910U
1430	Samsung	GT-N7000
1431	Samsung	GT-N7000
1432	Samsung	GT-P1000
1433	Samsung	GT-P1000L
1434	Samsung	GT-P1000N
1435	Samsung	GT-P1000T
1436	Samsung	GT-P6200L
1437	Samsung	GT-P6201
1438	Samsung	GT-S3100

Item	Brand Name	Model
1439	Samsung	GT-S3310i
1440	Samsung	GT-S3350
1441	Samsung	GT-S3353
1442	Samsung	GT-S3370
1443	Samsung	GT-S3370B
1444	Samsung	GT-S3370C
1445	Samsung	GT-S3370E
1446	Samsung	GT-S3370L
1447	Samsung	GT-S3500i
1448	Samsung	GT-S3501C
1449	Samsung	GT-S3550
1450	Samsung	GT-S3600i
1451	Samsung	GT-S3601C
1452	Samsung	GT-S3650
1453	Samsung	GT-S3650C
1454	Samsung	GT-S3650W
1455	Samsung	GT-S3653
1456	Samsung	GT-S3653W
1457	Samsung	GT-S3770
1458	Samsung	GT-S3770B
1459	Samsung	GT-S3770K
1460	Samsung	GT-S3770L
1461	Samsung	GT-S3770M
1462	Samsung	GT-S3770Y
1463	Samsung	GT-S3778
1464	Samsung	GT-S3778V
1465	Samsung	GT-S3850
1466	Samsung	GT-S3970
1467	Samsung	GT-S5150
1468	Samsung	GT-S5220
1469	Samsung	GT-S5222
1470	Samsung	GT-S5230
1471	Samsung	GT-S5230C
1472	Samsung	GT-S5230G
1473	Samsung	GT-S5230N
1474	Samsung	GT-S5233A
1475	Samsung	GT-S5233S
1476	Samsung	GT-S5233T
1477	Samsung	GT-S5233W
1478	Samsung	GT-S5250
1479	Samsung	GT-S5260
1480	Samsung	GT-S5260P
1481	Samsung	GT-S5270K
1482	Samsung	GT-S5270L
1483	Samsung	GT-S5270Y
1484	Samsung	GT-S5273L
1485	Samsung	GT-S5330
1486	Samsung	GT-S5333
1487	Samsung	GT-S5350
1488	Samsung	GT-S5350L
1489	Samsung	GT-S5360
1490	Samsung	GT-S5360B
1491	Samsung	GT-S5360L
1492	Samsung	GT-S5360T
1493	Samsung	GT-S5363
1494	Samsung	GT-S5368
1495	Samsung	GT-S5369
1496	Samsung	GT-S5380
1497	Samsung	GT-S5380B
1498	Samsung	GT-S5380D
1499	Samsung	GT-S5380K
1500	Samsung	GT-S5380L
1501	Samsung	GT-S5510
1502	Samsung	GT-S5510T
1503	Samsung	GT-S5511T
1504	Samsung	GT-S5520
1505	Samsung	GT-S5530
1506	Samsung	GT-S5560
1507	Samsung	GT-S5560C
1508	Samsung	GT-S5560i
1509	Samsung	GT-S5570
1510	Samsung	GT-S5570B
1511	Samsung	GT-S5570I

Item	Brand Name	Model
1512	Samsung	GT-S5570L
1513	Samsung	GT-S5571
1514	Samsung	GT-S5578
1515	Samsung	GT-S5580
1516	Samsung	GT-S5600
1517	Samsung	GT-S5600B
1518	Samsung	GT-S5600H
1519	Samsung	GT-S5600L
1520	Samsung	GT-S5600T
1521	Samsung	GT-S5600V
1522	Samsung	GT-S5603
1523	Samsung	GT-S5603T
1524	Samsung	GT-S5608U
1525	Samsung	GT-S5610
1526	Samsung	GT-S5620
1527	Samsung	GT-S5620B
1528	Samsung	GT-S5620L
1529	Samsung	GT-S5628
1530	Samsung	GT-S5628i
1531	Samsung	GT-S5660
1532	Samsung	GT-S5660B
1533	Samsung	GT-S5660L
1534	Samsung	GT-S5660M
1535	Samsung	GT-S5660V
1536	Samsung	GT-S5670
1537	Samsung	GT-S5670B
1538	Samsung	GT-S5670L
1539	Samsung	GT-S5690
1540	Samsung	GT-S5690L
1541	Samsung	GT-S5690L
1542	Samsung	GT-S5750E
1543	Samsung	GT-S5780
1544	Samsung	GT-S5820
1545	Samsung	GT-S5830
1546	Samsung	GT-S5830B
1547	Samsung	GT-S5830C
1548	Samsung	GT-S5830i
1549	Samsung	GT-S5830L
1550	Samsung	GT-S5830M
1551	Samsung	GT-S5830T
1552	Samsung	GT-S5838
1553	Samsung	GT-S6102
1554	Samsung	GT-S6102B
1555	Samsung	GT-S6700T
1556	Samsung	GT-S6703T
1557	Samsung	GT-S6888
1558	Samsung	GT-S7070
1559	Samsung	GT-S7070C
1560	Samsung	GT-S7220U
1561	Samsung	GT-S7230
1562	Samsung	GT-S7230B
1563	Samsung	GT-S7230E
1564	Samsung	GT-S7230L
1565	Samsung	GT-S7233E
1566	Samsung	GT-S7250
1567	Samsung	GT-S7250D
1568	Samsung	GT-S7350i
1569	Samsung	GT-S7350U
1570	Samsung	GT-S7500
1571	Samsung	GT-S7510
1572	Samsung	GT-S8000B
1573	Samsung	GT-S8000C
1574	Samsung	GT-S8000H
1575	Samsung	GT-S8000L
1576	Samsung	GT-S8000U
1577	Samsung	GT-S8500
1578	Samsung	GT-S8500
1579	Samsung	GT-S8500B
1580	Samsung	GT-S8500C
1581	Samsung	GT-S8500L
1582	Samsung	GT-S8500M
1583	Samsung	GT-S8500R
1584	Samsung	GT-S8530

Item	Brand Name	Model
1585	Samsung	GT-S8530B
1586	Samsung	GT-S8530L
1587	Samsung	GT-S8600
1588	Samsung	Highlight
1589	Samsung	i200
1590	Samsung	I450
1591	Samsung	i520
1592	Samsung	i640v
1593	Samsung	i7500 Galaxy
1594	Samsung	i780
1595	Samsung	i8000 Omnia
1596	Samsung	i8510
1597	Samsung	I8910
1598	Samsung	i8910 HD
1599	Samsung	i900 Omnia
1600	Samsung	i907 Epix
1601	Samsung	i910
1602	Samsung	Impression (A877)
1603	Samsung	Instinct HD (M850)
1604	Samsung	Instinct S30
1605	Samsung	Intensity
1606	Samsung	Intrepid (I350)
1607	Samsung	J200
1608	Samsung	J700
1609	Samsung	J758
1610	Samsung	J808
1611	Samsung	Jack i637
1612	Samsung	L708
1613	Samsung	L760
1614	Samsung	L770
1615	Samsung	M220
1616	Samsung	M310
1617	Samsung	M320
1618	Samsung	M330
1619	Samsung	M5650
1620	Samsung	M630
1621	Samsung	M7600
1622	Samsung	M7600
1623	Samsung	M8910
1624	Samsung	Magnet A257
1625	Samsung	Marcel Reloaded
1626	Samsung	Moment
1627	Samsung	Mythic A897
1628	Samsung	Pixon M8800
1629	Samsung	Propel (TM) Pro i627
1630	Samsung	Rant M540
1631	Samsung	Reclaim (M560)
1632	Samsung	Refurbished
1633	Samsung	Renown
1634	Samsung	Rogue
1635	Samsung	Rugby (A837)
1636	Samsung	S3030 Tobi
1637	Samsung	S3110C
1638	Samsung	S3500C
1639	Samsung	S3600H
1640	Samsung	S3650 Corby
1641	Samsung	S5230
1642	Samsung	S5500
1643	Samsung	S5550 Shark
1644	Samsung	S5560
1645	Samsung	S5600
1646	Samsung	S5628 Monte
1647	Samsung	S7070 Diva
1648	Samsung	S7350
1649	Samsung	S7350B
1650	Samsung	S7350C
1651	Samsung	S7350L
1652	Samsung	S8000
1653	Samsung	S8000 Jet
1654	Samsung	S8300
1655	Samsung	S8300C
1656	Samsung	S8300T
1657	Samsung	S8300V

Item	Brand Name	Model
1658	Samsung	SC-01B
1659	Samsung	SC-01C
1660	Samsung	SC-02B
1661	Samsung	SC-02C
1662	Samsung	SC-02C
1663	Samsung	SC-03D
1664	Samsung	SC-04D
1665	Samsung	SCH-F809
1666	Samsung	SCH-F859
1667	Samsung	SCH-I100
1668	Samsung	SCH-I110
1669	Samsung	SCH-i220
1670	Samsung	SCH-i220(MPCS)
1671	Samsung	SCH-i225
1672	Samsung	SCH-i329
1673	Samsung	SCH-I400
1674	Samsung	SCH-I405
1675	Samsung	SCH-I500
1676	Samsung	SCH-i509
1677	Samsung	SCH-I510
1678	Samsung	SCH-I515
1679	Samsung	SCH-I520
1680	Samsung	SCH-I559
1681	Samsung	SCH-I569
1682	Samsung	SCH-I579
1683	Samsung	SCH-I579i
1684	Samsung	SCH-I589
1685	Samsung	SCH-I800
1686	Samsung	SCH-I809
1687	Samsung	SCH-i889
1688	Samsung	SCH-i899
1689	Samsung	SCH-I909
1690	Samsung	SCH-I909L
1691	Samsung	SCH-i919
1692	Samsung	SCH-I920
1693	Samsung	SCH-I929
1694	Samsung	SCH-M710
1695	Samsung	SCH-M715
1696	Samsung	SCH-M720
1697	Samsung	SCH-M828C
1698	Samsung	SCH-P739
1699	Samsung	SCH-P739
1700	Samsung	SCH-R100
1701	Samsung	SCH-R220
1702	Samsung	SCH-R250
1703	Samsung	SCH-R260
1704	Samsung	SCH-R260
1705	Samsung	SCH-R260
1706	Samsung	SCH-R260
1707	Samsung	SCH-R261
1708	Samsung	SCH-R311
1709	Samsung	SCH-R312
1710	Samsung	SCH-R330
1711	Samsung	SCH-R330
1712	Samsung	SCH-R335
1713	Samsung	SCH-R350
1714	Samsung	SCH-R351
1715	Samsung	SCH-R360
1716	Samsung	SCH-R380
1717	Samsung	SCH-R455
1718	Samsung	SCH-R520
1719	Samsung	SCH-R560
1720	Samsung	SCH-R570
1721	Samsung	SCH-R580
1722	Samsung	SCH-R630
1723	Samsung	SCH-R631
1724	Samsung	SCH-R631 2Thumb
1725	Samsung	SCH-R640
1726	Samsung	SCH-R641
1727	Samsung	SCH-R680
1728	Samsung	SCH-R700
1729	Samsung	SCH-R710
1730	Samsung	SCH-R720

Item	Brand Name	Model
1731	Samsung	SCH-R730
1732	Samsung	SCH-R760
1733	Samsung	SCH-R850
1734	Samsung	SCH-R860
1735	Samsung	SCH-R880
1736	Samsung	SCH-R880
1737	Samsung	SCH-R900
1738	Samsung	SCH-R910
1739	Samsung	SCH-R915
1740	Samsung	SCH-R920
1741	Samsung	SCH-R930
1742	Samsung	SCH-R940
1743	Samsung	SCH-U350
1744	Samsung	SCH-U350
1745	Samsung	SCH-U360
1746	Samsung	SCH-U365
1747	Samsung	SCH-U370
1748	Samsung	SCH-U380
1749	Samsung	SCH-U430
1750	Samsung	SCH-U450
1751	Samsung	SCH-U450
1752	Samsung	SCH-U450
1753	Samsung	SCH-U450(Verizon)
1754	Samsung	SCH-U460
1755	Samsung	SCH-U480
1756	Samsung	SCH-U640
1757	Samsung	SCH-U660
1758	Samsung	SCH-U820
1759	Samsung	SCH-U960
1760	Samsung	SCH-W279
1761	Samsung	SCH-W309
1762	Samsung	SCH-W689
1763	Samsung	SCH-W899
1764	Samsung	SCH-W999
1765	Samsung	SGH-A967
1766	Samsung	SGH-C414
1767	Samsung	SGH-C414M
1768	Samsung	SGH-C414R
1769	Samsung	SGH-C414V
1770	Samsung	SGH-C414W
1771	Samsung	SGH-C414Y
1772	Samsung	SGH-I577
1773	Samsung	SGH-i677
1774	Samsung	SGH-I717
1775	Samsung	SGH-I717D
1776	Samsung	SGH-I717M
1777	Samsung	SGH-I717R
1778	Samsung	SGH-I727
1779	Samsung	SGH-I727R
1780	Samsung	SGH-I757
1781	Samsung	SGH-I777
1782	Samsung	SGH-I777
1783	Samsung	SGH-I807
1784	Samsung	SGH-I807
1785	Samsung	SGH-I827
1786	Samsung	SGH-i847
1787	Samsung	SGH-I857
1788	Samsung	SGH-I896
1789	Samsung	SGH-I897
1790	Samsung	SGH-I897
1791	Samsung	SGH-i917
1792	Samsung	SGH-I917R
1793	Samsung	SGH-I927
1794	Samsung	SGH-I927R
1795	Samsung	SGH-i937
1796	Samsung	SGH-I937
1797	Samsung	SGH-I997
1798	Samsung	SGH-I997
1799	Samsung	SGH-I997R
1800	Samsung	SGH-J600E
1801	Samsung	SGH-S425G
1802	Samsung	SGH-T245G
1803	Samsung	SGH-T249R

Item	Brand Name	Model
1804	Samsung	SGH-T259
1805	Samsung	SGH-T269
1806	Samsung	SGH-T330G
1807	Samsung	SGH-T369R
1808	Samsung	SGH-T379
1809	Samsung	SGH-T499
1810	Samsung	SGH-T499W
1811	Samsung	SGH-T499Y
1812	Samsung	SGH-T589
1813	Samsung	SGH-T589R
1814	Samsung	SGH-T669V
1815	Samsung	SGH-T669V
1816	Samsung	SGH-T669Y
1817	Samsung	SGH-T669Y
1818	Samsung	SGH-T679
1819	Samsung	SGH-T679M
1820	Samsung	SGH-T759
1821	Samsung	SGH-T769
1822	Samsung	SGH-T839
1823	Samsung	SGH-T869
1824	Samsung	SGH-T939
1825	Samsung	SGH-T959
1826	Samsung	SGH-T959
1827	Samsung	SGH-T959D
1828	Samsung	SGH-T959D
1829	Samsung	SGH-T959D
1830	Samsung	SGH-T959P
1831	Samsung	SGH-T959V
1832	Samsung	SGH-T959W
1833	Samsung	SGH-T989
1834	Samsung	SGH-T989D
1835	Samsung	SHC-Z120L
1836	Samsung	SHV-E110S
1837	Samsung	SHV-E110S
1838	Samsung	SHV-E120K
1839	Samsung	SHV-E120L
1840	Samsung	SHV-E120S
1841	Samsung	SHV-E150S
1842	Samsung	SHV-E160K
1843	Samsung	SHV-E160L
1844	Samsung	SHV-E160S
1845	Samsung	SHW-A280K
1846	Samsung	SHW-A280L
1847	Samsung	SHW-A280S
1848	Samsung	SHW-A300K
1849	Samsung	SHW-A300S
1850	Samsung	SHW-A310S
1851	Samsung	SHW-M100S
1852	Samsung	SHW-M110S
1853	Samsung	SHW-M110S
1854	Samsung	SHW-M110S
1855	Samsung	SHW-M110S
1856	Samsung	SHW-M115S
1857	Samsung	SHW-M120S
1858	Samsung	SHW-M130K
1859	Samsung	SHW-M130K
1860	Samsung	SHW-M130L
1861	Samsung	SHW-M130L
1862	Samsung	SHW-M135K
1863	Samsung	SHW-M135L
1864	Samsung	SHW-M180K
1865	Samsung	SHW-M180L
1866	Samsung	SHW-M180S
1867	Samsung	SHW-M180W
1868	Samsung	SHW-M185S
1869	Samsung	SHW-M190S
1870	Samsung	SHW-M200K
1871	Samsung	SHW-M200S
1872	Samsung	SHW-M210S
1873	Samsung	SHW-M220L
1874	Samsung	SHW-M240K
1875	Samsung	SHW-M240S
1876	Samsung	SHW-M250K

Item	Brand Name	Model
1877	Samsung	SHW-M250K
1878	Samsung	SHW-M250L
1879	Samsung	SHW-M250L
1880	Samsung	SHW-M250S
1881	Samsung	SHW-M250S
1882	Samsung	SHW-M290K
1883	Samsung	SHW-M290S
1884	Samsung	SHW-M340K
1885	Samsung	SHW-M340L
1886	Samsung	SHW-M340S
1887	Samsung	SHW-M410K
1888	Samsung	SHW-M410S
1889	Samsung	SHW-M420K
1890	Samsung	SHW-M420S
1891	Samsung	Smooth
1892	Samsung	Solstice (TM) (A887)
1893	Samsung	SPH-D600
1894	Samsung	SPH-D600
1895	Samsung	SPH-D700
1896	Samsung	SPH-D705
1897	Samsung	SPH-D710
1898	Samsung	SPH-D710
1899	Samsung	SPH-D720
1900	Samsung	SPH-i350
1901	Samsung	SPH-L700
1902	Samsung	SPH-M260
1903	Samsung	SPH-M330
1904	Samsung	SPH-M340
1905	Samsung	SPH-M350
1906	Samsung	SPH-M360
1907	Samsung	SPH-M370
1908	Samsung	SPH-M380
1909	Samsung	SPH-M380
1910	Samsung	SPH-M550
1911	Samsung	SPH-M560
1912	Samsung	SPH-M560
1913	Samsung	SPH-M570
1914	Samsung	SPH-M575
1915	Samsung	SPH-M580
1916	Samsung	SPH-M580
1917	Samsung	SPH-M580 BST
1918	Samsung	SPH-M7200
1919	Samsung	SPH-M7350
1920	Samsung	SPH-M820
1921	Samsung	SPH-M8400
1922	Samsung	SPH-M850
1923	Samsung	SPH-M900
1924	Samsung	SPH-M900
1925	Samsung	SPH-M910
1926	Samsung	SPH-M930
1927	Samsung	SPH-M930
1928	Samsung	SPH-P100
1929	Samsung	Steel U900
1930	Samsung	Stratosphere
1931	Samsung	SWD-S500
1932	Samsung	t229
1933	Samsung	t239
1934	Samsung	t349
1935	Samsung	T559 Comeback
1936	Samsung	T659
1937	Samsung	t819
1938	Samsung	T929 Memoir
1939	Samsung	Trance
1940	Samsung	u440
1941	Samsung	U808
1942	Samsung	X01SC
1943	Samsung	A637
1944	Samsung	A657
1945	Samsung	Galaxy S i9000
1946	Samsung	M520
1947	Samsung	T339
1948	Samsung	u430
1949	Samsung	Wave S8500

Item	Brand Name	Model
1950	Sanyo	Incognito (SCP-6760)
1951	Sanyo	Katana Eclipse
1952	Sanyo	Katana LX
1953	Sanyo	PRO-700
1954	Sanyo	SCP-2700
1955	Sanyo	SCP-3810
1956	Seals Technologies Limited	VR7
1957	Sharp	102SH
1958	Sharp	ADS1
1959	Sharp	P1FD50C
1960	Sharp	P1FD52C
1961	Sharp	SH-01D
1962	Sharp	Sharp® FX™ PLUS
1963	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips E122
1964	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W527
1965	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W625
1966	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W626
1967	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W715
1968	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W725
1969	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W727
1970	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W820
1971	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X525
1972	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X526
1973	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X528
1974	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips X623
1975	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips Xenium X325
1976	Shenzhen Sang Fei Consumer Communications Co., Ltd	Philips W920
1977	Shenzhen Tinno Mobile Technology Corp.	T521
1978	SK telesys	SK-S150
1979	Sonim	Sonim XP1300-A-R1 (Type: P25B005AA)
1980	Sonim	Sonim XP1300-E-R1 (Type: P24B005AA)
1981	Sonim	Sonim XP1301-A-R1 (Type: P25B005AN)
1982	Sonim	Sonim XP1301-E-R1 (Type: P24B005AN)
1983	Sonim	Sonim XP3300-A-R1 (Type: P25C005AA)
1984	Sonim	Sonim XP3300-A-X1 (Type: P25C005AJ)
1985	Sonim	Sonim XP3300-A-Y1 (Type: P25C005AJ)
1986	Sonim	Sonim XP3300-E-R1 (Type: P24C005AA)
1987	Sonim	Sonim XP3300-E-X1 (Type: P24C005AJ)
1988	Sonim	Sonim XP3300-E-Y1 (Type: P24C005AJ)
1989	Sonim	Sonim XP3340-E-R1 (Type: P24C005AA)
1990	Sonim	Sonim XP3400-A-R1 (Type: C21F007AA)
1991	Sonim	Sonim XP5300-A-R1 (Type: P35F006AA)
1992	Sonim	Sonim XP5300-E-R1 (Type: P34F006AA)
1993	Sony	Equinox
1994	Sony	Sony Xperia™ TL
1995	Sony	Xperia™ ion by Sony
1996	Sony Ericsson	Aino
1997	Sony Ericsson	Aino/ U10
1998	Sony Ericsson	ASPEN
1999	Sony Ericsson	C510 Black
2000	Sony Ericsson	C510, C510a
2001	Sony Ericsson	C901
2002	Sony Ericsson	C901, C901a
2003	Sony Ericsson	C902
2004	Sony Ericsson	C903, C903a
2005	Sony Ericsson	C905 Black
2006	Sony Ericsson	CDMA SOI11
2007	Sony Ericsson	Cedar?
2008	Sony Ericsson	Elm
2009	Sony Ericsson	F100i
2010	Sony Ericsson	F305
2011	Sony Ericsson	G502
2012	Sony Ericsson	G700
2013	Sony Ericsson	G705
2014	Sony Ericsson	G900
2015	Sony Ericsson	Hazel
2016	Sony Ericsson	J105 (Naite)
2017	Sony Ericsson	J105i
2018	Sony Ericsson	Live with Walkman
2019	Sony Ericsson	Mix Walkman
2020	Sony Ericsson	S302
2021	Sony Ericsson	S51SE
2022	Sony Ericsson	Satio/ U1

Item	Brand Name	Model
2023	Sony Ericsson	SO-01C
2024	Sony Ericsson	SO-01D
2025	Sony Ericsson	SO-03C
2026	Sony Ericsson	Sony Ericsson A8i
2027	Sony Ericsson	Sony Ericsson R800
2028	Sony Ericsson	Sony Ericsson txt
2029	Sony Ericsson	T650i
2030	Sony Ericsson	T700
2031	Sony Ericsson	T707, T707a
2032	Sony Ericsson	T715
2033	Sony Ericsson	T715
2034	Sony Ericsson	TM506
2035	Sony Ericsson	TM717
2036	Sony Ericsson	txt pro™
2037	Sony Ericsson	U10
2038	Sony Ericsson	Vivaz
2039	Sony Ericsson	Vivaz pro
2040	Sony Ericsson	W300i
2041	Sony Ericsson	W302
2042	Sony Ericsson	W350 (Refurbished)
2043	Sony Ericsson	W350a
2044	Sony Ericsson	W508, W508a
2045	Sony Ericsson	W518a
2046	Sony Ericsson	W518a
2047	Sony Ericsson	W580i
2048	Sony Ericsson	W595
2049	Sony Ericsson	W660i
2050	Sony Ericsson	W705
2051	Sony Ericsson	W705, W705u, W705a
2052	Sony Ericsson	W715
2053	Sony Ericsson	W760a
2054	Sony Ericsson	W810i
2055	Sony Ericsson	W850i
2056	Sony Ericsson	W960i
2057	Sony Ericsson	W980
2058	Sony Ericsson	W995, W995a
2059	Sony Ericsson	WT18
2060	Sony Ericsson	Xperia acro
2061	Sony Ericsson	Xperia arc
2062	Sony Ericsson	Xperia mini
2063	Sony Ericsson	Xperia mini pro
2064	Sony Ericsson	Xperia neo V
2065	Sony Ericsson	Xperia PLAY
2066	Sony Ericsson	Xperia pro
2067	Sony Ericsson	Xperia Pureness/ X5
2068	Sony Ericsson	Xperia X1
2069	Sony Ericsson	Xperia X10
2070	Sony Ericsson	Xperia X10 mini (Rev 2)
2071	Sony Ericsson	Xperia X10 mini pro (Rev2)
2072	Sony Ericsson	Xperia? X8
2073	Sony Ericsson	Xperia™ acro
2074	Sony Ericsson	Xperia™ active
2075	Sony Ericsson	Xperia™ arc S
2076	Sony Ericsson	Xperia™ neo
2077	Sony Ericsson	Xperia™ ray
2078	Sony Ericsson	Yari
2079	Sony Ericsson	Z310a
2080	Sony Ericsson	Z750a
2081	Sony Ericsson	Z770i
2082	Sony Ericsson	Zylo?
2083	Sony Ericsson	Aion U10
2084	Sony Ericsson	C903
2085	Sony Ericsson	Elm J10
2086	Sony Ericsson	F100
2087	Sony Ericsson	Hazel J20
2088	Sony Ericsson	K510a
2089	Sony Ericsson	K660i
2090	Sony Ericsson	Satio U1i
2091	Sony Ericsson	Vivaz U5
2092	Sony Ericsson	W395
2093	Sony Ericsson	W902
2094	Sony Ericsson	W995
2095	Sony Ericsson	X10

Item	Brand Name	Model
2096	Sony Ericsson	X10 mini
2097	Sony Ericsson	X10 mini pro
2098	Sony Ericsson	X2
2099	Sony Ericsson	Yari U100
2100	Sony Ericsson	Z550a
2101	Sony Ericsson	Z555
2102	TCT Mobile Suzhou Limited	JukeB
2103	TCT Mobile Suzhou Limited	MOVE/ one touch 908/ one touch 908A/ one touch 908S/ one touch 908M/ one touch 908F
2104	TCT Mobile Suzhou Limited	one touch 318D
2105	TCT Mobile Suzhou Limited	one touch 506/ one touch 506D / one touch 506A
2106	TCT Mobile Suzhou Limited	one touch 536
2107	TCT Mobile Suzhou Limited	one touch 585/ 585D/ 585A
2108	TCT Mobile Suzhou Limited	one touch 602/ 602D/ 602A
2109	TCT Mobile Suzhou Limited	one touch 632D
2110	TCT Mobile Suzhou Limited	one touch 665/ one touch 665A
2111	TCT Mobile Suzhou Limited	one touch 678G
2112	TCT Mobile Suzhou Limited	one touch 803/ one touch 803A/ one touch 813/ one touch 813D/ one touch 813A/ one touch 819/ one touch 819A/ one touch 819D/ one touch 809/ one touch 813F/ one touch 803F
2113	TCT Mobile Suzhou Limited	one touch 810/ one touch 810A/ one touch 810D
2114	TCT Mobile Suzhou Limited	one touch 818/ one touch 818A/ one touch 818D
2115	TCT Mobile Suzhou Limited	one touch 888/ one touch 888A/ one touch 888D
2116	TCT Mobile Suzhou Limited	one touch 890/ one touch 890D
2117	TCT Mobile Suzhou Limited	one touch 891
2118	TCT Mobile Suzhou Limited	one touch 900M/ one touch 900/ one touch 901A/ one touch 901S/ one touch 901N/ one touch 901D/ one touch 900A
2119	TCT Mobile Suzhou Limited	one touch 905/ 905A/ 907N/ 905M
2120	TCT Mobile Suzhou Limited	one touch 906/ one touch 906Y
2121	TCT Mobile Suzhou Limited	one touch 909B
2122	TCT Mobile Suzhou Limited	one touch 910/ one touch 909A/ one touch 909M/ one touch 909S/ one touch 910A
2123	TCT Mobile Suzhou Limited	one touch 913D/ one touch 913K/ one touch 913N
2124	TCT Mobile Suzhou Limited	one touch 918/ one touch 918A/ one touch 918D/ one touch 918N/ one touch 918M/ TCL A919/ OT 918
2125	TCT Mobile Suzhou Limited	one touch 985/ one touch 985A/ one touch 985S/ one touch 985N/ TCL A966/ OT 985
2126	TCT Mobile Suzhou Limited	one touch 990/ one touch 990A/ one touch 990S/ one touch 990M/ Vodafone 958
2127	TCT Mobile Suzhou Limited	OT-799/ OT-799A
2128	TCT Mobile Suzhou Limited	S by SFR 3440
2129	TCT Mobile Suzhou Limited	TCL-7110
2130	TCT Mobile Suzhou Limited	TCL-8107
2131	TCT Mobile Suzhou Limited	Vodafone 355
2132	TCT Mobile Suzhou Limited	Vodafone 455
2133	TCT Mobile Suzhou Limited	Vodafone 555 Blue
2134	T-Mobile	G2
2135	T-Mobile	MyTouch 3G Slide
2136	T-Mobile	MyTouch 4G
2137	T-Mobile	T-Mobile Wing (S730)
2138	Tsb Plus Deal Corp	EYO DESERT 6
2139	Tsb Plus Deal Corp	EYO E97
2140	Tsb Plus Deal Corp	X95
2141	UT Starcom	CDM8950
2142	UT Starcom	GZ1 C711
2143	ZTE	1001
2144	ZTE	003Z
2145	ZTE	a5
2146	ZTE	Android Edition Starnaute
2147	ZTE	BJK1903
2148	ZTE	BLADE
2149	ZTE	C F350
2150	ZTE	F160
2151	ZTE	F870
2152	ZTE	F870
2153	ZTE	F870E
2154	ZTE	F930
2155	ZTE	F950
2156	ZTE	F951
2157	ZTE	F951
2158	ZTE	F951E
2159	ZTE	F952 UM KP
2160	ZTE	Jack 3G

Item	Brand Name	Model
2161	ZTE	San Francisco
2162	ZTE	T870
2163	ZTE	T930
2164	ZTE	Tactile internet 2
2165	ZTE	U X990
2166	ZTE	U X991
2167	ZTE	Venus
2168	ZTE	Vodafone 945
2169	ZTE	XCD35
2170	ZTE	008Z
2171	ZTE	008Z
2172	ZTE	009Z
2173	ZTE	Android edition by sfr STARADDICT
2174	ZTE	Android Edition Star Text
2175	ZTE	Android Edition StarTrail
2176	ZTE	Arizona
2177	ZTE	Atrial
2178	ZTE	BASE Lutea 2
2179	ZTE	BLADE II
2180	ZTE	Blade S
2181	ZTE	C D930
2182	ZTE	C D980
2183	ZTE	C F450
2184	ZTE	C X769
2185	ZTE	CARL/ ZTE-U V852
2186	ZTE	E821
2187	ZTE	E821S
2188	ZTE	F116/ F116/ ZTE-U F116
2189	ZTE	F451
2190	ZTE	G N285
2191	ZTE	G N292
2192	ZTE	G N295/ Sydney/ Affinity
2193	ZTE	G R228
2194	ZTE	G R230
2195	ZTE	G R235
2196	ZTE	G R236
2197	ZTE	G R250
2198	ZTE	G R252
2199	ZTE	G R260
2200	ZTE	G V821
2201	ZTE	G X730
2202	ZTE	KPN Smart 200
2203	ZTE	Libra
2204	ZTE	Light Tab 2W
2205	ZTE	MEDION Smartphone LIFE P4310
2206	ZTE	MEDION Smartphone LIFE P4310
2207	ZTE	Monte Carlo
2208	ZTE	Movistar One
2209	ZTE	Movistar Vega
2210	ZTE	N285
2211	ZTE	N850
2212	ZTE	N860
2213	ZTE	RacerII
2214	ZTE	RacerII
2215	ZTE	S by SFR 116
2216	ZTE	S by SFR 344
2217	ZTE	San Francisco II
2218	ZTE	San Francisco II
2219	ZTE	SKATE/ ZTE Skate
2220	ZTE	Skate/ ZTE SKATE/ ZTE-SKATE
2221	ZTE	Skate4.3 H
2222	ZTE	T12
2223	ZTE	T28
2224	ZTE	T28
2225	ZTE	T50
2226	ZTE	T60
2227	ZTE	tmn smart a7
2228	ZTE	TQ150
2229	ZTE	Tureis
2230	ZTE	Tureis
2231	ZTE	U E850
2232	ZTE	U F110
2233	ZTE	U F953 / MIMOSA

Update: 09/13/2013

MA3222/MA3222-17/MA3222-16 BT Compatibility list

Item	Brand Name	Model
2234	ZTE	U V857
2235	ZTE	U V859
2236	ZTE	U V875m
2237	ZTE	U V960
2238	ZTE	U X720
2239	ZTE	U5100
2240	ZTE	U6100
2241	ZTE	V6000
2242	ZTE	V860
2243	ZTE	V871
2244	ZTE	V875
2245	ZTE	V960
2246	ZTE	Vivacity
2247	ZTE	Vodafone 351
2248	ZTE	Vodafone 550
2249	ZTE	webphones Android™ by sfr STARTEXT II
2250	ZTE	Windows Phone-Internet 7
2251	ZTE	X500
2252	ZTE	X500
2253	ZTE	X500M
2254	ZTE	Z331
2255	ZTE	Z431
2256	ZTE	Z990