
Go to **www.vtechphones.com** to register your product for enhanced warranty support and latest VTech product news.







Quick start guide


VM351














































Talk to your baby unit

Press and hold TALK and speak to your parent unit. Your voice is transmitted to the baby unit.



Turn off the screen

Press and hold LCD ON/OFF to switch off the screen. You can still hear sound from the baby



· Press any keys on the parent unit to turn on the

Press MENU/SELECT to enter the menu, choose a menu item, or save a setting. You can use the parent unit menu for the advanced settings or operations, such as to play or stop the baby unit lullaby, or to adjust the baby unit sound

While in the menu:

- Press ▲ or ▼ to scroll up or down.
- Press > to select an item.
- Press ≺ to return to the main menu or idle



Turn off the parent unit

Press and hold POWER to power off your parent unit.



Basic operation - Baby unit

Press + VOL - to adjust your baby unit speaker volume. It determines the lullaby volume and

Adjust speaker volume



Press ▶/■ to play lullaby on the baby unit.

 Press ➤ to to play the next lullaby. Press ►/■ again to stop the lullaby.




Turn off the baby unit

Slide the **ON/OFF** switch to **OFF** to power off your baby unit.



Mount the baby monitor (optional)





Check for reception strength and


Place the wall mount bracket on a wall and then use a pencil to mark the top and the bottom holes as shown Remove the wall mount bracket and drill two holes in the wall (7/32 inch drill bit).

camera angle before drilling the holes.

If you drill the holes into an object other than a stud, insert the wall anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the wall.

If you drill the holes into a stud,


go to step 3.



Align the wall mount bracket and screws with the holes in the wall as shown. Tighten the screw in the middle hole first, so that the wall mount bracket position is fixed. You can tighten the other screw in the top hole.




Place the baby unit on the wall mount bracket. Tighten the screw into the threaded socket at the bottom to secure the baby unit.



Insert the screws into the holes and tighten the screws until only 1/4 inch of the screws are exposed.



Place the baby unit on the wall mount bracket. Tighten the screw into the threaded socket at the bottom to secure the baby unit. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place.



The default angle of the wall mount bracket is 90 degrees. You can maximize your baby unit's viewing angles by tilting the wall mount bracket.

Hold the baby unit, and then rotate the knob in anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to tighten the joint and secure the angle.

